

SERVICE REMINDERS

CR-V PHEV/FHEV, Civic 5D/Civic Type R, HR-V, ZR-V, Jazz, e:Ny1, Honda e - English



AUTOMOBILE WORKING TIME FRAME

Hybrid & Petrol Vehicles

SYMBOL	SERVICE REMINDER SYSTEM	CR-V FHEV		CR-V PHEV	CIVIC	HR-V	JAZZ	ZR-V	CIVIC TYPE-R
		2WD	4WD	2WD					
A*0	Replace engine oil and oil filter	0.4	0.4	0.4	0.5	0.5	0.5	0.4	0.5
B*0	Inspect front and rear brakes	1.1	1.1	1.1	1.1	1.1	1.2	1.1	0.6
	Inspect tie-rod ends, steering gearbox and boots								
	Inspect suspension components								
	Inspect driveshaft boots								
	Inspect brake hoses and lines including ABS/VSA lines								
	Inspect all fluid levels and condition of fluids								
	Inspect exhaust system								
	Inspect fuel lines and connections								
	Inspect tyre condition								
	Inspect under body battery cover (PHEV only)								
	Check expiry date for TRK (Temporary Repair Kit) bottle								
	Test Drive (noise, stability, dashboard operation)								
	Check lights alignment								
	Inspect vehicle corrosion *1								
	Annual inspection of the High Voltage Battery Health. Only for certain full hybrid models.								
2	Replace dust and pollen filter *2	0.2	0.2	0.2	0.2	0.1	0.1	0.1	0.2
3	Replace transmission fluid *4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4
4	Replace fuel filter *3	1.1	1.1	1.2	1.6	1.7	1.4	1.4	1.6
5	Replace engine coolant	0.9	0.9	0.9	0.6	0.6	0.6	0.8	0.4
6	Replace rear differential fluid (FHEV only)	-	0.3	-	-	-	-	-	-
7	Replace brake fluid	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.5
8	Replace air cleaner element *5	0.2	0.2	0.2	0.2	0.5	0.1	0.2	0.2
	Replace spark plugs *6 (HR-V only)								
9	Replace spark plugs *7 (All models excluding HR-V)	0.4	0.4	0.4	0.4	2.7	2.2	0.4	2.2
	Check valve clearance *8 (Jazz, HR-V and Type R only)								

Electric Vehicles

SYMBOL	SERVICE REMINDER SYSTEM	e:Ny1	Honda e
B	Check front and rear brakes	1.3	1
	Inspect tie-rod ends, steering gearbox and boots		
	Inspect suspension components		
	Inspect driveshaft boots		
	Inspect brake hoses and lines including ABS/VSA lines		
	Inspect all fluid levels and condition of fluids		
	Check expiration date for TRK (Temporary Repair Kit) bottle		
	Test drive (noise, stability, dashboard operation)		
	Check lights alignment		
	Inspect vehicle corrosion *1		
	Inspect tyre condition		
	IPU (including IPU guard and cover)		
	Annual High Voltage Battery Health Check		
0	Inspect IPU	0.1	-
2	Replace dust and pollen filter *2	0.2	0.2
3	Replace transmission fluid *4	0.4	0.4
7	Replace brake fluid	0.4	0.4

*No.	HR-V	Jazz	Type R	Civic	CR-V PHEV	CR-V FHEV	ZR-V	Honda e	e:Ny1
	Under the following conditions, maintenance for certain items is required independent of the multi information display.								
0	Subtract 0.2 if symbols A and B are displayed together, to adjust for duplication.								
1	If item B appears before one year has passed, inspect for vehicle corrosion every year.								
2	When you drive primarily in urban areas that have high concentrations of soot in the air, under dusty conditions, or when the air flow from the heating and cooling system/climate control system becomes weak, replace the filter every 20,000 km (12,500 miles) or every year. (30,000km/18,500 miles for CR-Vs)								
3	It is recommended that you replace the fuel filter every 110,000 km (68,500 miles) if the fuel you are using is suspected to be contaminated with dust, etc because the filter may be clogged sooner.				It is recommended that you replace the fuel filter every 130,000 km (81,000 miles) if the fuel you are using is suspected to be contaminated with dust, etc because the filter may be clogged sooner.				
4			Driving in mountainous areas at very low/high speeds results in higher transmission temperatures. This required transmission fluid changes more frequently than recommended by the service reminder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 60,000 km.					Driving in mountainous areas at very low/high speeds results in higher transmission temperatures. This required transmission fluid changes more frequently than recommended by the service reminder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 50,000 km.	
5	If you drive in dusty conditions, replace every 30,000 km (18,750 miles).								
6	More than 10% of driving time above 130km/h, replace the spark plugs every 40,000km.								
7			If you drive at speeds over 200 km/h for more than 50% of driving time, replace the spark plugs every 60,000 km.		If you drive at speeds over 160 km/h for more than 50% of driving time, replace the spark plugs every 70,000 km.				
8	Sensory Method: Adjust the valves during service 120,000 km if they are noisy.								